

## EPCS DEACTIVATION

## 1. POWER DOWN PCS

Close all display windows

At the Taskbar on bottom of Display:

```
sel      EXIT
```

On 'Logout Confirmation' window:

sel OK

## When 'Type any key to continue' appears

PCS PCS 1, 2 Thinkpad PWR switches → OFF

PWR SPLY      PCS1 DC PWR SPLY PWR switch → OFF (Lt off)

PCS2 DC PWR SPLY PWR switch → OFF (Lt off)

TBD                      DC UTIL PWR → OFF

PDIP      PDIP UTIL PWR → OFF

## 2. DISCONNECT EPCS POWER AND DATA CABLE

|      |   |
|------|---|
| PDIP | Disconnect both Orb 1553 Data cables to (PDIP Data Ports 1, 2) outlet<br>1553 PC Card Adapter Cable |
|------|---|

Disconnect both 6 foot Orb DC PWR SPLY cable to DC UTIL PWR outlet  
DC PWR SPLY outlet (J1)

Disconnect both 25 foot DC PWR SPLY cable to EPCS DC PWR outlet  
DC PWR SPLY outlet (J2)

### 3. STOW PCS

TBD

- PCS - Two Thinkpads
- Two DC PWR SPLYs
- Two 25 foot DC PWR cables
- Two 6 foot DC PWR SPLY cables
- Two ORB 1553 Data Cables